# TC8300 Touch Computer





# **Quick Start Guide**

#### Copyright

ZEBRA and the stylized Zebra head are trademarks of Zebra Technologies Corporation, registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners. ©2019 Zebra Technologies Corporation and/or its affiliates. All rights reserved.

COPYRIGHTS & TRADEMARKS: For complete copyright and trademark information, go to www.zebra.com/copyright.

WARRANTY: For complete warranty information, go to www.zebra.com/warranty.

END USER LICENSE AGREEMENT: For complete EULA information, go to www.zebra.com/eula.

#### **Terms of Use**

Proprietary Statement

This manual contains proprietary information of Zebra Technologies Corporation and its subsidiaries ("Zebra Technologies"). It is intended solely for the information and use of parties operating and maintaining the equipment described herein. Such proprietary information may not be used, reproduced, or disclosed to any other parties for any other purpose without the express, written permission of Zebra Technologies.

Product Improvements

Continuous improvement of products is a policy of Zebra Technologies. All specifications and designs are subject to change without notice.

· Liability Disclaimer

Zebra Technologies takes steps to ensure that its published Engineering specifications and manuals are correct; however, errors do occur. Zebra Technologies reserves the right to correct any such errors and disclaims liability resulting therefrom.

Limitation of Liability

In no event shall Zebra Technologies or anyone else involved in the creation, production, or delivery of the accompanying product (including hardware and software) be liable for any damages whatsoever (including, without limitation, consequential damages including loss of business profits, business interruption, or loss of business information) arising out of the use of, the results of use of, or inability to use such product, even if Zebra Technologies has been advised of the possibility of such damages. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

#### Warranty

For the complete Zebra hardware product warranty statement, go to: www.zebra.com/warranty.

#### **Service Information**

Before you use the unit, it must be configured to operate in your facility's network and run your applications.


If you have a problem using your equipment, contact your facility's Technical or Systems Support. If there is a problem with the equipment, they will contact the Zebra Global Customer Support at www.zebra.com/support.

For the latest version of this guide go to: www.zebra.com/support.


#### **Provide Documentation Feedback**

If you have comments, questions, or suggestions about this guide, send an email to <a href="EVM-Techdocs@zebra.com">EVM-Techdocs@zebra.com</a>.

#### **Features**




## **Battery Installation**



# **Charge the TC8300**

1. Insert the TC8300 into the cradle.



2. The TC8300 starts to charge automatically. The TC8300 charges in approximately four hours.

LED State	Description
Solid Amber	Device is charging.
Solid Green	Device is fully charged.
Fast Blinking Red	Charging error.
Off	Not charging.

# **Scanning**

To scan barcodes:

- 1. Open an application and ensure that a text field is in-focus.
- 2. Press the trigger and aim the exit window at a barcode.

### TC8300 Quick Start Guide



